

# >VIP Connecting link-VVS<



## Safety instruction

This safety instruction/declaration has to be kept on file for the whole lifetime of the product.

### Translation of the original safety instruction

This safety instruction is valid in addition to the safety instructions for RUD Sling chains (VIP-No. 7101649 and MAXI-Nr. 7900639).



**RUD Ketten**  
**Rieger & Dietz GmbH u. Co. KG**  
 73428 Aalen  
 Tel. +49 7361 504-1370  
 Fax +49 7361 504-1171  
 sling@rud.com  
 www.rud.com

RUD-Art.-Nr.: 7901477-EN / 02.017

## VIP Connecting link-VVS VIP Round sling connector RS-VVS to attach roundslings

**EC-Mounting declaration**

According to the EC-Machinery Directive 2006/42/EC, annex II B and amendments

Manufacturer: **RUD Ketten**  
**Rieger & Dietz GmbH u. Co. KG**  
 Friedensinsel  
 73432 Aalen

We hereby declare that the following incomplete machines correspond to the basic requirements of the Machinery Directive 2006/42/EC (annex 1). The following incomplete machine, in the delivered machine, may only be put into operation when the machine in which the incomplete machine shall be assembled, has been tested according to the requirements of the EC-Machinery Directive 2006/42/EC.

**Product name:** Chain coupling  
VVS

The following harmonized norms were applied:

<u>DIN EN 1677-1 : 2009-03</u>	<u>DIN EN ISO 12100 : 2011-03</u>
_____	_____
_____	_____
_____	_____

The following national norms and technical specifications were applied:

<u>BGR 500, KAP2.8 : 2008-04</u>	_____
_____	_____
_____	_____
_____	_____

The special documents about the incomplete machine according to annex VII part B have been created and can be handed over in a suitable form on request.

Authorized person for the configuration of the declaration documents:  
 Michael Betzler, RUD Ketten, 73432 Aalen

Aalen, den 26.09.2016 Dr.-Ing. Arne Kriegsmann, (Prokurist/QMB) *Arne Kriegsmann*  
 Name, function and signature of the responsible person

**EG-Einbauerklärung**

entsprechend der EG-Maschinenrichtlinie 2006/42/EG, Anhang II B und ihren Änderungen

Hersteller: **RUD Ketten**  
**Rieger & Dietz GmbH u. Co. KG**  
 Friedensinsel  
 73432 Aalen

Hiermit erklären wir, dass die nachfolgend bezeichnete unvollständige Maschine den grundlegenden Anforderungen der Maschinenrichtlinie 2006/42/EG (Anhang 1) entspricht. Die nachfolgend bezeichnete unvollständige Maschine darf, in der gelieferten Ausführung erst dann in Betrieb genommen werden, wenn festgestellt wurde, dass die Maschine, in die diese unvollständige Maschine eingebaut werden soll, den Anforderungen der EG-Maschinenrichtlinie 2006/42/EG entspricht.

**Produktbezeichnung:** Verbindungsschloss  
VVS

Folgende harmonisierten Normen wurden angewandt:

<u>DIN EN 1677-1 : 2009-03</u>	<u>DIN EN ISO 12100 : 2011-03</u>
_____	_____
_____	_____
_____	_____

Folgende nationalen Normen und technische Spezifikationen wurden außerdem angewandt:

<u>BGR 500, KAP2.8 : 2008-04</u>	_____
_____	_____
_____	_____
_____	_____

Die speziellen Unterlagen zur unvollständigen Maschine nach Anhang VII Teil B wurden erstellt und werden auf begründetes Verlangen in geeigneter Form übermittelt.

Für die Zusammenstellung der Konformitätsdokumentation bevollmächtigte Person:  
 Michael Betzler, RUD Ketten, 73432 Aalen

Aalen, den 26.09.2016 Dr.-Ing. Arne Kriegsmann, (Prokurist/QMB) *Arne Kriegsmann*  
 Name, Funktion und Unterschrift Verantwortlicher



Before initial usage of the VIP Connecting link, please read carefully the safety instructions. Make sure that you understand all subjected matters. Nonobservance can lead to serious personal injuries and material damage and eliminates warranty.

## 1 Safety instructions



### ATTENTION

Wrong assembled or damaged lifting and lashing means as well as improper use can lead to injuries of persons and damage of objects when load drops down. Please inspect all lifting points before each use.

- Please be also aware of extreme circumstances or shock loads when selecting the used Connecting link or the components.
- In each half of the connecting link only one load bearing strand or a corresponding component must be attached.
- VIP-Connecting links must only be used by instructed and competent persons considering BGR 500 (DGUV rules 100-500) and outside Germany noticing the country specific statutory regulations.

## 2 Intended use

VIP connecting links are designed to connect components with an eye to sling chains or wire rope fittings.

They must only be used in the hereby described operation purpose for lifting resp. for the transport of loads and as lashing component in combination with VIP lashing chains.

## 3 Assembly- and instruction manual

### 3.1 General information

- Capability of temperature usage:  
When using the VIP-Connecting links at temperatures beyond 200°C the permissible WLL of the ICE-Connecting links has to be reduced as follows:  
-40°C up to 200°C no reduction  
200° up to 300°C minus 10 %  
300° up to 380°C minus 40 %  
Temperatures exceeding 380°C are prohibited!  
The temperature characteristics of te whole sling assembly depends in the properties of the sling components. F.e. polyester round slings, and other components with an eye.
- VIP-Connecting links must not be used with aggressive chemicals such as acids, alkaline solutions and their vapours.

### 3.2 Hints for the assembly

Please observe the following during the assembly of the VVS: At the max. an eye with a diameter of a 2-leg-VIP Masterlink can be assembled.



### ATTENTION

Overloading or wrong loading of the connecting link can lead to fall of load. Doing this serious injuries or property damage can occur.

In each half of the connecting link **only one load bearing strand** or a corresponding component must be attached



Pic 1:  
Correct assembly  
and usage



Pic 2:  
Wrong assembly  
and usage.  
Only one load bearing  
strand is permissible



### HINT

Lifting points, shakles and plate clamps can be attached into the halves of the connecting link.

Basically essential:

- Only VVS-connecting link components with H1-10 stamping must be assembled
- Observe in any case during assembly the correct dimensioning of the connecting parts
- Use only original RUD spare parts.
- The VIP control link VCG can be used as an overload indicator when assembled with a VIP3-link piece (bypass) as a middle part between the two halves of the connector (pic. 3).
- Check finally the correct assembly (see chapter 4 Inspection criteria).




Pic 3:  
VIP-assembly link VCG

### 3.3 Sequence of assembly


In the following description the assembly of the connecting link will be described exemplarily with the example of a masterlink and an VIP chain.

1. Install last chain link into the single bow eye (Pic. 4). In this case there is no additional connector necessary.




#### HINT


At the beginning of the bow rounding, chain link can be turned by 90° within the bow (Pic. 5)




2. Position chain strand to the bottom of the bow part (Pic. 6).



3. Put into the second bow part a desired connecting part, f.e. a masterlink (Pic. 7).




4. Assemble both bow parts together in such a way that components are aligned (Pic. 8).



5. Install pin into the bore of the eye (Pic. 9). Both bow parts are now connected with each other.

6. Secure the assembled connecting link as follows (Pic. 10):

- Position both securing pins/sleeve pins in such a way, that the slot faces the outside.
- Knock both sleeve pins in with a hammer.



7. Finally Check the correct assembly (see chapter 4 Inspection criteria).

### 3.4 User instructions

- Check before each loading of the connecting link, that connecting pin is installed correct in the bow eye. Secure pin by hammering the sleeve pins in.
- Make sure that the load force happens in the straight leg without being twisted, fold-over or kinked.
- Control frequently and before each operation the total lifting in regard of ongoing ability, strong corrosion, wear, deformation etc. (see chapter 4 Inspection criteria).



#### ATTENTION

*Wrong assembled or damaged lifting and lashing means as well as improper use can lead to injuries of persons and damage of objects when load drops down. Please inspect all lifting points before each use.*

- Leave hazardous area when possible.
- Watch always attached loads.
- Read for all lifting means the RUD sling chain Safety instructions for RUD lifting means.

### 3.5 Hints for regular inspection

Check by a competent person in periods, which are determined by usage but at least 1x year, the continuous appropriateness of the lifting means (see chapter 4 Inspection criteria).

Depending on the working conditions, f.e. when often used, or if increased wear or corrosion occurs, inspections could be necessary in shorter periods than one year.


Denomination	WLL [kg]	A [mm]	B [mm]	C [mm]	D [mm]	E [mm]	T [mm]	weight [kg/pc.]	Ref.-no.
VVS 6	1,500	18	55	13	11	17	46	0.12	7901438
VVS 8	2,500	24	70	18	14	23	61	0.29	7901439
VVS 10	4,000	28	88	22	17	27	74	0.57	7901440
VVS 13	6,700	34	111	28	23	33	93	1.2	7901441
VVS 16	10,000	39	130	33	27	37	108	2.0	7901442
VVS 20	16,000	42	154	41	34	41	124	3.7	7901443
VVS 22	20,000	48	172	44	37	46	138	4.8	7901444
VVS 28 - MAXI	31,500	69	228	58	47	67	189	10.6	7901445
RS-VVS 28*	31,500	69	160	100	47	33	245	20.1	7903511

Chart 1: Dimensioning


\*to attach roundslings

Technical alterations subject to change

RUD components are tested in accordance with DIN EN 1677, with a minimum of 20.000 load cycles at 1.5 x WLL. At high dynamical loads with high number of load cycles the bearing stress must be reduced acc. to FEM Group 1Bm (M3 acc. To DIN EN 818-7).



Pic. 11: VVS 6 up to 28



Pic. 12: RS-VVS-28

## 4 Inspection criteria

Check and control the following points before each initial operation, in periodical periods after the assembly and after special incidents:

- Completeness of the VIP Connecting link
- Readable size and manufacturer sign
- Mechanical damage like strong notches, especially in areas where tensile stress occurs
- Damaging and reduction of cross section caused by wear > 10 %, especially at connecting pins and at the eyes of the VVS bows.
- Cracks or other damage

## 5 Hints for repairing

- Repairs must only be carried out by competent persons, which can show that they have the therefor necessary skills.
- Only RUD original spare parts must be used and all repairing and overhauling operations must be documented in the chain card file (of the complete lifting mean) or use the RUD-ID-System®.